



SPERRY  
Since 1935

# HOW TO RELACE YOUR BOAT SHOES



1. TAPER THE END OF THE LACE (USE SPERRY RELACING KIT AND A PAIR OF SCISSORS)



3. PLACE LACE ONTO THE NEEDLE



4. BEGIN BY LACING THROUGH THE INSIDE OF THE BOTTOM EYELET ON ONE SIDE



## 5. PUSH NEEDLE THROUGH EACH EYELET



6. FLATTEN THE BACK OF THE SHOE TO LET THE NEEDLE IN EASIER



7. THREAD NEEDLE THROUGH THE OUTSIDE OF LAST EYELET ON THE BOTTOM



## 8. REMOVE NEEDLE FROM THE LACE



## 9. FINISH BY CROSSING THE LACES THROUGH THE LAST EYELETS



DONE!





**SPERRY**

*Since 1935*